

Wing Sheeting Preparation

1. **Straighten the Edges** – Use a metal ruler and an X-Acto knife to trim a thin sliver off each edge of your balsa sheets to ensure they are perfectly straight.
2. **Join the Sheets** – Place the sheets together and secure them with $\frac{3}{4}$ " (18 mm) masking tape.
3. **Glue the Edges** – Fold the sheets open, apply a bead of white glue along the edge, then lay them flat (glue side up).
4. **Remove Excess Glue** – Use a stiff piece of cardboard to scrape off any extra glue.
5. **Let It Dry** – Place masking tape over the seams again and allow the glue to dry for at least 6 hours.
6. **Final Step** – Remove the tape and mark the side where glue was scraped off—this is the side that will be coated with wing adhesive and attached to the cores.

